

# PHYS 798C Spring 2024

## Lecture 27 Summary

Prof. Steven Anlage

### I. KT IN 2D SUPERCONDUCTORS: ISOLATED VORTEX VS. V/AV ENERGIES

Vortices in 2D superconductors are similar to those discussed before in 3D superconductors except for the tails. Instead of having the currents falling off exponentially with distance for  $r > \lambda$  in 3D, one instead has a surface current given by,

$$\mu_0 \vec{K}_s(r) = \frac{\Phi_0}{2\pi} \hat{\theta} \times \begin{cases} \frac{d/\lambda^2}{r} & r \ll 2\lambda^2/d \\ \frac{1}{r^2} & r \gg 2\lambda^2/d \end{cases}$$

See the paper by Pearl, Appl. Phys. Lett. 5, 65 (1964), posted on the class web site. The key things to note are the  $1/r^2$  drop-off of the surface currents with distance, and the crossover length scale, called the perpendicular penetration depth  $\lambda_{\perp} = 2\lambda^2/d$ , where  $d$  is the film thickness. The crossover length scale can be macroscopic in size in low carrier density and/or disordered superconducting films of small (nm) thickness. The other case is a Josephson junction array, where the screening length is the Josephson penetration depth  $\lambda_J \sim 1/\sqrt{J_c}$ . By making the junction critical current density  $J_c$  small, the Josephson screening length can be in excess of many  $\mu m$ . Thus the  $1/r$  “core” of the vortices can extend over macroscopic distances! The vortices now act like Coulomb charges interacting in a 2D metal, or like vortices in thin films of superfluid  $^4\text{He}$ .

The energy of a free vortex can be calculated by ignoring the vortex core (GL  $\kappa \rightarrow \infty$ ) and considering only the kinetic energy of the currents as,

$W_1 = \pi n_{s,2D}^* \frac{\hbar^2}{m^*} \ln \frac{R}{r_0}$ , where  $n_{s,2D}^* = n_s L$  is the 2D superfluid density,  $n_s$  is the 3D superfluid density,  $L$  is the length of the vortex (on the order of the film thickness),  $r_0$  is the microscopic length scale where the current density approaches the de-pairing value (we expect  $r_0 \sim \xi_{GL}$ ), and  $R$  is the sample size, where it is assumed that  $\lambda_{\perp}$  is much greater than the sample size. The energy of a single isolated vortex depends on the system size, making it very expensive!

Contrast this with the case of a V/AV pair at some distance  $r$  apart. Far away ( $R \gg r$ ) the flow fields of the two vortices cancel to good approximation, making the object appear “neutral” from far away. The currents are strong only within  $r$ , giving rise to a total energy of just,

$$W_2 = 2\pi n_{s,2D}^* \frac{\hbar^2}{m^*} \ln \frac{r}{r_0}.$$

Because  $W_2 \ll W_1$  the V/AV excitations are the dominant excitations at low temperature in the extreme 2D superconductor.

The basic idea of KT-physics is that the elementary excitations out of the ground state are vortex/anti-vortex (V/AV) pairs. This will be the case in the limit of  $\lambda_{\perp} \gg R$ , which is, admittedly, pretty exotic. Josephson junction arrays are the best way to get to this extreme 2D limit with superconductors. Your run of the mill Nb or Al thin films of thickness 10 nm, or so, are nowhere near this limit! In these cases, the Bogoliubons are the dominant excitations out the ground state.

The vortex/anti-vortex pairs are bound together at low temperatures and do not dissipate energy. The bound pairs can be dissociated by means of a strong transport current, giving rise to dissipation, and this process will be calculated later. Otherwise, an increase in temperature leads to the possibility of a thermal excitation of a single vortex. This process is the basis for the calculation of the Kosterlitz-Thouless transition temperature.

### II. THE KOSTERLITZ-THOULESS PHASE TRANSITION FOR 2D SUPERCONDUCTORS

To naively estimate the KT transition temperature  $T_{KT}$ , calculate the Helmholtz free energy of a free vortex,  $\Delta F_1 = W_1 - TS_1$  and see where it changes sign. The entropy  $S_1$  comes from counting the number of microscopic configurations that give the same macroscopic properties. In the case of a free vortex added to the sample, the vortex could be located in any square of size  $a$ , where  $a$  is expected to be on the order of  $r_0$ . Thus the Helmholtz free energy can be written as,

$$\Delta F_1 = W_1 - k_B T \ln(R^2/r_0^2).$$

This can be expanded as,

$$\Delta F_1 = \left( \pi n_{s,2D}^* \frac{\hbar^2}{m^*} - 2k_B T \right) \ln \frac{R}{r_0} - 2k_B T \ln \frac{r_0}{a}.$$

In the thermodynamic limit  $R \rightarrow \infty$  only the first term survives. (Also we expect  $\ln \frac{r_0}{a} \sim 0$  since both  $r_0$  and  $a$  are on the scale of the vortex core size.)

Looking at the temperature where  $\Delta F_1 = 0$  yields this implicit equation for  $T_{KT}$ :

$n_{s,2D}^*(T_{KT}) = \frac{2m^*k_B}{\pi\hbar^2} T_{KT}$ . One can find  $T_{KT}$  by finding the intersection of  $n_{s,2D}^*(T)$  and the line described by  $\frac{2m^*k_B}{\pi\hbar^2} T$ . The class web site shows such data from superfluid  $^4\text{He}$  and  $\text{In}/\text{InO}_x$  superconducting films. From those plots one can see that the superfluid density is heading to zero at some higher mean field transition temperature,  $T_{c0}$ , but the V/AV fluctuations, and their un-binding, interrupts this mean field transition at a lower temperature  $T_{KT}$ . Hence this is a fluctuation-dominated phase transition.

### III. HIGHLIGHTS OF KT PHYSICS IN 2D SUPERCONDUCTORS

For temperatures above  $T_{KT}$  one can define a free-vortex correlation length  $\xi_+(T) \sim r_0 e^{\sqrt{B \frac{T_{KT}}{T - T_{KT}}}}$ , where  $B$  is a constant of order unity. For length scales less than  $\xi_+(T)$  there are no free vortices. Hence  $\xi_+^2(T)$  is a measure of the puddle size of free-vortex-free regions. Note that this length scale diverges as  $T_{KT}$  is approached from above. One can use it to estimate the free vortex density as  $n_f(T) = 1/\xi_+^2(T)$ , for  $T > T_{KT}$ . The free vortex density thus goes to zero at  $T_{KT}$ . The free vortices will dissipate energy when acted upon by an external current, thus  $T_{KT}$  can be found from the zero-resistance state of the material, in principle. An estimate of the resistivity of the sample is made in analogy with the Bardeen-Stephen law used in Lecture 20 (the total resistivity is the normal state resistivity times the fractional area coverage of vortex cores):  $\rho(T) = \rho_n \frac{r_0^2}{\xi_+^2(T)}$ , where  $\rho_n$  is the normal state resistivity of the film. This gives a very specific prediction for the resistivity temperature dependence above  $T_{KT}$ .

Now think about what happens below  $T_{KT}$  in the presence of a finite current. When a transport current is applied to a bound V/AV pair, the Lorentz force will act in opposite directions on each vortex and act to stretch the pair. This gives rise to a peak in the energy of the V/AV pair as a function of separation  $r$ . The V/AV pair can unbind due to a thermal fluctuation activating the system over the barrier, creating free vortices below  $T_{KT}$ . The free-vortex generation rate is given by

$$G = G_0 e^{-E_0/k_B T}, \text{ where } E_0 = q^2 \ln \left( \frac{q^2}{r_0 \Phi_0 j_{2D}} \right) \text{ is the height of the energy barrier, } G_0 \text{ is the attempt}$$

frequency for jumping over the barrier,  $q^2(T) = \frac{2\pi\hbar^2 n_{s,2D}^*(T)}{m^*}$ , and  $j_{2D} = LJ_s$  is the 2D surface current density. With these definitions, the free vortex generation rate is,

$$G = G_0 \left( \frac{r_0 \Phi_0 j_{2D}}{q^2} \right)^{q^2/k_B T}.$$

But free vortices generated this way can also re-combine and annihilate. This recombination rate is given by  $R = R_0 n_f^2$ , where  $n_f$  is the free vortex density induced by the finite current below  $T_{KT}$ .

By assuming a dynamic equilibrium and equating the generation and recombination rates, we can calculate the free vortex density as,

$$n_f = \sqrt{\frac{G_0}{R_0}} \left( \frac{r_0 \Phi_0 j_{2D}}{q^2} \right)^{q^2/2k_B T}, \text{ for } T < T_{KT} \text{ in the presence of a current.}$$

Assuming  $\rho \sim E/j_{2D} \sim n_f$ , then these free vortices will create a longitudinal electric field given by,

$E \sim j_{2D}^a(T)$  with  $a(T) = 1 + \frac{\pi\hbar^2 n_{s,2D}^*(T)}{m^* k_B T}$ . This exponent has the value of 3 at  $T_{KT}$ , and a value of 1 above  $T_{KT}$  (Ohmic dissipation due to free vortices, calculated above). More generally, the  $E - j_{2D}$  relation

can be written as  $E \sim j_{2D}^{1+2 \frac{T_{KT}}{T} \frac{n_{s,2D}^*(T)}{n_{s,2D}^*(T_{KT})}}$ . This form shows that the exponent grows, starting from a value of 3, for  $T < T_{KT}$ . Thus the IV curves show a discontinuous jump in slope from 1 to 3 at  $T_{KT}$ , followed by a steady rise below that temperature. The large value of the exponent at low temperature resembles a finite critical current.

Along with this there is a discontinuous drop to zero in superfluid density  $n_{s,2D}^*$  at  $T_{KT}$ . This can be seen from the fact that the  $E - j_{2D}$  exponent is  $a(T) = 1 + \frac{\pi\hbar^2 n_{s,2D}^*(T)}{m^* k_B T}$ , which must equal 1 when  $T > T_{KT}$ , hence this requires that  $n_{s,2D}^* = 0$  above  $T_{KT}$ . The abrupt drop in superfluid/super-electron density at  $T_{KT}$  is a universal property of the KT transition.